




How BMW 3 Series E90 - E93 Big Brake Kit Install

Step-by-step instructions for BMW 3 Series E90 - E93 Big Brake Kit Installation. Credit: longtran E90Post.com

Written By: Albert Smythe






TOOLS:

- [Big Brake Kit](#) (1)
- [17/18mm Socket](#) (1)
- [Socket Wrench](#) (1)
- [14mm Open End Wrench](#) (1)
- [Adjustable Wrench](#) (1)
- [Vise Grip Wrench](#) (1)
- [6mm Hex Wrench](#) (1)
- [Brake Line Pincher](#) (1)
- [Dremel](#) (1)
- [Cut Off Disc](#) (1)
- [Zip Ties](#) (1)

Step 1 — Procedure



- Remove 2 18mm bolt that hold the caliper. you can remove the caliper and use some zip ties to hang it somewhere.

Step 2 — Loosen the Face of Rotor




- Loosen the 6mm hex on the face of the rotor.

Step 3 — Rotor Removal



- Remove the rotor.

Step 4 — Pinch the Brake Line



- Now pinch the brake line with the pincher.

Step 5 — Loosen the Brake Line




- With a 14mm open end wrench unloose the brake line from the caliper.
- Now you should have everything off.

Step 6 — Trim the Corners



- Trim the corners with the dremel so the bigger caliper can clear the heat shield.
- Before (2nd photo)
- After (3rd photo)
- Now reverse the install with the bbk. install the stainless steel brake lines if your kit comes with them.

Step 7 — Tighten the Brake Line



- Tighten the brake line on the caliper first and find something to hang it. Here some pictures putting the BBK on.
- Now install the rotor.

Step 8 — Bolt the Caliper



- Bolt the caliper on.
- The brake sensor does not work in BBK. just zip tie the sensor somewhere, so it wont get tangle while you are driving.

Step 9 — Bleed the Brakes



- Now bleed the brakes. have fun!!!