



# RX350 Oil Change

Oil & Filter Change RX350

Written By: DriveDIY



## Step 1 — Open Hood and Locate Oil Cap and Dipstick



- Oil Cap
- DipStick

## Step 2 — Drive onto Ramps



- Using vehicle ramps, drive up to gain clearance.
- Oil Drain
- Using a 17mm Wrench , open the drain valve.

⚠ Oil may be HOT!



### Step 3 — Remove Oil Filter Drain Cap



- Using a 3/8" square socket adapter , remove drain cap
- The replacement oil filter will include a plastic drain nipple that can be screwed into this to facilitate draining the excess oil inside the oil filter housing

### Step 4 — Remove the Oil Filter Housing Cap



- Using a Lexus/Toyota adapter , remove the oil filter housing cap

## Step 5 — Replace O-Rings on filter housing



- New O Rings are included in the new filter kit.

## Step 6 — Replace drain plug gasket



- Always replace this gasket when doing an oil change.

## Step 7 — Re Install Filter and Drain Plug



- Replace Filter and Drain Plug once all oil has been drained.

## Step 8 — Add Oil



- Add 6 Qts of Lexus Approved 0w-20 Oil
- Check dip stick and top off accordingly
- ① Lexus States that complete oil change and filter will use 6.4 qt